



**JATON TEC**




## **Quick User Guide**


JT4500H

## ❖ Device Package

Products	Quantity
ODU Unit	1
IDU Unit	1
48V DC Power Adapter	1
Ethernet Cable	1
Clamps	30~82mm 2, 27~51mm 2
Quick User Guide	1

## ❖ Device External Interface





## ❖ Environmental Specification

Feature	Specs.
Operating temperature	ODU: -40 to 55°C, IDU: -15 to 50°C
Storage temperature	-45 to 85°C
Operating humidity	0 to 95% No condensation

## ❖ Getting Your Device Ready for Connection

### Step 1

#### Insert the SIM CARD (ODU)

Before powering on the device, please insert the SIM card in the direction indicated on the bottom of the device.



### Step 2

#### Installing Outdoor Unit

Use the clamps provided in the packaging to secure the equipment onto the pole.



## Step 3

### Grounding

Make sure that the installation of the outdoor unit, antenna and cables is performed in accordance with all relevant national and local building and safety codes. Even where grounding is not mandatory according to applicable regulation and national codes, it is highly recommended to ensure that the outdoor unit and the antenna mast are grounded and suitable lightning protection devices are used so as to provide protection against voltage surges and static charges.

The Grounding screw is located on the lower part at the back of the unit (see Figure below). Use 10 AWG cable for grounding.




### Power on

Before connecting the device to AC power, please refer to the diagram and connect the PoE port of the ODU to the PoE port of the IDU using an Ethernet cable. Once the connection is confirmed to be reliable, connect the power adapter provided with the device to the power input port of the IDU and then turn on the power switch of the IDU device. The SYS light of the IDU device will illuminate.




## ❖ LED Display



(ODU)

LED	Function	Description
PWR	Power indicator	Light is on – Device is power on.
SYS	System run indicator	Blinking Blue – Device is booting. Solid Blue– Device is in normal operation.
NET	WAN port status	OFF – NO wireless network access. Blinking Blue – 3G link is up and operational Solid Blue –LTE/5G link is up and operational
SIM	SIM card indicator	Light is on – SIM card state is ready, Blinking Blue – SIM card is error.
ETH	LAN port status	Solid Blue – LAN port is up. Blinking Blue –LAN port in working.
RF (5LEDs)	RF Signal Strength	5 level signal strengths indication by 5 green LEDs. 1st Green LED: $-140\text{dBm} < \text{RSRP} < -115\text{dBm}$ 2nd Green LED: $-115\text{dBm} \leq \text{RSRP} < -105\text{dBm}$ 3rd Green LED: $-105\text{dBm} \leq \text{RSRP} < -95\text{dBm}$ 4th Green LED: $-95\text{dBm} \leq \text{RSRP} < -85\text{dBm}$ 5th Green LED: $-85 \leq \text{RSRP}$




(IDU)

LED	Function	Descriptions
SYS	System Indicator	Solid Orange - Device powering up and booting. Solid Green - Normal operation. Blinking Orange - SIM card absent or malfunction detected.
NET	Mobile Network Indicator	OFF - Not yet connected to mobile network. Solid Green - Connected to 4G network.
RF	RF Signal Strength	RF1 Blinking Green - Device searching for mobile network entry. RF1 Solid Green: $-140\text{dBm} \leq \text{RSRP} < -115\text{dBm}$ RF2 Solid Green: $-115\text{dBm} \leq \text{RSRP} < -105\text{dBm}$ RF3 Solid Green: $-105\text{dBm} \leq \text{RSRP} < -95\text{dBm}$ RF4 Solid Green: $-95\text{dBm} \leq \text{RSRP}$
2.4GHz	2.4GHz Wi-Fi status	OFF - 2.4GHz Wi-Fi is not enabled. Solid Green - 2.4GHz Wi-Fi is enabled. Fast Blinking - Data is being transmitted. Slow Blinking - Device 2.4GHz Wi-Fi WPS is activated.
5GHz	5GHz Wi-Fi status	OFF - 5GHz Wi-Fi is not enabled. Solid Green - 5GHz Wi-Fi is enabled. Fast Blinking - Data is being transmitted. Slow Blinking - Device 5GHz Wi-Fi WPS is activated.
LINE	Line Status Indicator	OFF - Line is not registered or provisioned. Solid Green - The line is ready and registered. Fast Blinking - Line is ringing. Slow Blinking - Voice call is in progress.

## ❖ WEB login


It is preferred to setup the CPE using a Web browser from a local PC connected to device LAN port. The operator should ensure that the connected PC has acquired IP address via DHCP from the device. After IP connectivity is established between the PC and CPE device, the operator may launch a Web browser and specify **http://192.168.0.1** in the address bar. A window will pop up requesting password. Input the user login password and then click the “Login” button. After successful log on, the default home page of the WEB GUI interface will appear.

Note the default password is “**admin**”.



## ❖ Device Status

Once the user is logged in, the following window device status window will be prompted for viewing. It contains both the system information, networking and device information configured for the device.






## ❖ LAN Setting

The LAN setting allows user to specify the device LAN IP, DHCP server setting, Local DNS etc. When Router mode is selected, the DHCP server should be enabled by default.

User is advised to leave the default setting unchanged for quick configuration and smooth device operation.




The screenshot shows the LAN Setting configuration page. The left sidebar contains navigation options: Device Status, Wireless Settings, Network Settings (selected), Wi-Fi Settings, Data Services, VoIP Settings, and Management. The main content area is titled 'LAN Setup' and includes the following fields:

- LAN Setup:** IP Address (192.168.0.1), Subnet Mask (255.255.255.0), MAC Address (6C:AD:EF:FE:B1:EE).
- DHCP Server Configuration:** DHCP Server (checked), Start IP Address (192.168.0.100), End IP Address (192.168.0.200), Lease Time (1440), DNS Server Address Mode (Auto), and DNS Proxy (checked).
- Statically Assigned:** A table with columns for IP Address and MAC Address, containing three rows of placeholder text (XXX.XXX.XXX.XXX).

An 'Apply' button is located at the bottom right of the configuration area.

## ❖ Wi-Fi Setting

In the Wi-Fi (2.4GHz or 5GHz) configuration, the operator can modify the default SSID and select the desired Security Policy to protect device Wi-Fi access. For easy configuration, the operator can use one of the following three recommended common security policies for setup.



The screenshot shows the Wi-Fi Setting configuration page. The left sidebar contains navigation options: Device Status, Wireless Settings, Network Settings, Wi-Fi Settings (selected), WPS Settings, Access Management, Active Access Points, Data Services, VoIP Settings, and Management. The main content area is titled 'Wi-Fi Settings' and includes the following fields:


- 2.4G Wi-Fi Setup / 5G Wi-Fi Setup:** Enable 2.4G Wi-Fi Network (checked).
- Network Name (SSID):** imaginelTE-FEB1EE, with a 'Hidden' checkbox.
- Password:** A masked password field with a 'Visible passwords' checkbox.
- Security Mode:** WPA-PSK/WPA2-PSK.
- Network Mode:** 802.11b/g/n Mixed Mode.
- Frequency (Channel):** AutoSelect.
- Channel Bandwidth:** 40 MHz.
- Maximum STAs:** 0.

An 'Apply' button is located at the bottom right of the configuration area.

## ❖ WPS Setting


The WPS setting allows user to enable or disable Wi-Fi WPS service.

The device is equipped with WPS function. Press the WPS button on the top of the device (IDU), and the Wi-Fi indicator light of the device will be blinking to indicate that the WPS function of the device has been activated. Within 120 seconds, activate the WPS function of the nearby computer or mobile device at the same time to automatically connect to the device's Wi-Fi without any other operation




## ❖ Port Forwarding Settings

This menu allows user to configure the port forwarding rules for the CPE in router mode.




## ❖ UPnP

This menu allows user to configure the UPnP application for on-demand “DMZ” support. The current forwarding rules created can be viewed and cleared if required.




## ❖ DMZ

This menu allows user to configure the DMZ setting for CPE in router mode. Web server, Telnet/SSH and Ping Service port can be exempted from DMZ mapping if required. By enabling DMZ option will make the specified local LAN host (DMZ IP) exposed to Internet.




## ❖ Security Setting

The menu allows user to configure the security & ALG setting.



## ❖ VoIP Settings


The menu allows user to configure the VoIP setting.



User Configurations	
Port Status	Unregistered
Receive Port	5060
User Name	
Account	
Password	

## ❖ Maintenance

The menu allows user to restart the device or load factory default.



Restart the Device	
Restart the Device	<a href="#">Restart</a>

Load Factory Default	
Load Factory Default	<a href="#">Load Default</a>

## ❖ Hardware reset

In case of user forgets the login password, the user can press and hold the RESET button in the back of the unit for 5 seconds. The unit will reset to factory default setting and reboot. Please wait until the unit finishes rebooting to regain access the device WEB GUI using default login credentials.

After device reset, if the device cannot connect to the network, please contact the operator or distributor for further support. Additional device provision may be required.

## ❖ FAQ and Troubleshooting

Problem	Description
My PC cannot connect to the CPE.	<ul style="list-style-type: none"> <li>• Re-plug the PC Ethernet cable and check if PC LAN connection is up or showing activity.</li> <li>• Check if the SYS LED is on. If it is not, check the power cord and make sure it is connected properly. Also verify that the AC power supply is available.</li> <li>• If the PC LAN shows no activity and CPE SYS LED is off but the power cord and ETH cable are connected properly and there is AC supply, then it is likely the power adapter is damaged. Please contact distributor to obtain replacement part.</li> </ul>
My PC cannot acquire IP from the CPE.	<ul style="list-style-type: none"> <li>• First check if the PC network interface card (NIC) is up and working properly. Then check the PC network interface card configuration and make sure the DHCP is enabled.</li> <li>• To release and renew the correct IP address, please unplug the Ethernet cable from the PC and wait for about 5 seconds, then connect it again.</li> <li>• If the problem persists, please contact the operator or distributor for further diagnoses.</li> </ul>
My CPE networking is not working properly.	<ul style="list-style-type: none"> <li>• You may want to check if the mobile connection is up and running properly. You can do this by login the WEB GUI and check the Interface Info page.</li> <li>• You may want to perform a factory reset and see if the problem is being corrected. You can do this by log into the WEB GUI using “admin” password and perform restore the unit to default factory setting.</li> <li>• If the problem cannot be corrected by factory reset, please contact the operator or distributor for further diagnoses.</li> </ul>
My PC cannot connect to the CPE Wi-Fi.	<ul style="list-style-type: none"> <li>• Please check and confirm if the SSID and password information for connecting to the device are consistent with the current configuration.</li> <li>• Perform a reset on the device to restore its configuration to the factory default settings, and then use the default Wi-Fi connection information provided on the device label to connect.</li> <li>• If the problem cannot be corrected by factory reset, please contact the operator or distributor for further diagnoses.</li> </ul>